


# Quick-Start Guide

LTE Weight Scale




## Pylo 200-LTE


### HOW TO USE



**INSERT THE BATTERIES**  
Open the battery compartment on the back of the scale and insert the provided 4 AA batteries.




**TAKE YOUR WEIGHT**  
Step on the scale with both feet and keep still. When you see your weight display and blink twice, step off the scale.



### DATA TRANSMISSION


- Once weight is locked in, the scale will transmit your data over the cellular mobile network.
- When data is successfully transmitted, "OK" will be displayed.
- If data transfer fails, "Er" will be displayed.
- In case of failure, the scale will save your current measurement and send it on the next successful transmission.

## SELECT MEASUREMENT UNIT



You can change the measurement unit by pressing the round button on the back of the scale. The scale unit will switch between pounds, kilograms and stones with each button press.

## HOW TO GET THE ACCURATE READINGS




- Place your scale on a flat, hard surface.

- Avoid using the scale on carpet or uneven tile.




- Keep both legs straight while the scale is measuring your weight. Avoid bending your knees!



- Take off bulky clothes and shoes.

- Make sure you are not touching or holding on to anything while weighing yourself.



- Take your weight at the same time each day.

For more information, see the full instruction manual.